
RASPERY
AMPLI
top
speaker
screen
padfront
kickplate
backtop
backmiddle
backbottom